

u-center

GNSS evaluation software for Windows

User Guide

Abstract

This document leads you through the efficient use of the u-center evaluation software, the powerful and easy to use tool from u-blox for evaluating, performance analysis and configuration of u-blox GNSS positioning chips and modules.



www.u-blox.com

UBX-13005250 – R11

Document Information

| | | |
|--------------------------|--------------------------------------|---------------|
| Title | u-center | |
| Subtitle | GNSS evaluation software for Windows | |
| Document type | User Guide | |
| Document number | UBX-13005250 | |
| Revision and date | R11 | 08-April-2016 |
| Document status | Production Information | |

Document status explanation

| | |
|------------------------------|--|
| Objective Specification | Document contains target values. Revised and supplementary data will be published later. |
| Advance Information | Document contains data based on early testing. Revised and supplementary data will be published later. |
| Early Production Information | Document contains data from product verification. Revised and supplementary data may be published later. |
| Production Information | Document contains the final product specification. |

This software uses parts of source code developed by other companies or groups.

JPG and JPEG graphics import filter:

Copyright © the Independent JPEG Group's software

PNG graphics import filter:

Copyright © 1998-2000 Glenn Randers-Pehrson,

Copyright (c) 1996, 1997 Andreas Dilger,

Copyright © 1995, 1996 Guy Eric Schalnat, Group 42, Inc.

TIFF graphics import filter:

Copyright © 1988-1997 Sam Leffler,

Copyright © 1991-1997 Silicon Graphics, Inc.

Docking views:

Copyright © 1998, 1999 by Cristi Posea

Perl Compatible Regular Expressions:

Copyright © 1997-2003 by University of Cambridge

Microsoft Foundation Class MFC4.2:

Copyright © Microsoft Corporation

All trademarks mentioned in this document are property of their respective owners.

u-blox reserves all rights to this document and the information contained herein. Products, names, logos and designs described herein may in whole or in part be subject to intellectual property rights. Reproduction, use, modification or disclosure to third parties of this document or any part thereof without the express permission of u-blox is strictly prohibited.

The information contained herein is provided "as is" and u-blox assumes no liability for the use of the information. No warranty, either express or implied, is given, including but not limited, with respect to the accuracy, correctness, reliability and fitness for a particular purpose of the information. This document may be revised by u-blox at any time. For most recent documents, visit www.u-blox.com.

Copyright © 2016, u-blox AG.

u-blox® is a registered trademark of u-blox Holding AG in the EU and other countries. ARM® is the registered trademark of ARM Limited in the EU and other countries.



Preface

Overview

u-center is u-blox's powerful GNSS evaluation and visualization tool which can be downloaded free-of-charge from our website (www.u-blox.com). This user guide provides a description of the features of this software. It allows end users to assess and test u-blox GNSS positioning chips and modules for navigation and positioning performance.

The purpose of u-center is to enable users to:

- Conduct performance tests on u-blox and other GNSS devices.
- Configure u-blox GNSS positioning chips and modules.
- Update the firmware on GNSS modules.
- Test the added performance provided by u-blox's AssistNow service.

Using this guide

This guide assumes that the user has basic computer skills and is familiar with the Windows Graphical User Interface (GUI) and GNSS receiver environments.

The following symbols are used to highlight important information:



An index finger points out key information pertaining to integration and performance.



A warning symbol indicates actions that could negatively impact or damage the receiver.

Technical support

If you have questions about installing or using u-center:

- Read this user guide carefully.
- Check our homepage (<http://www.u-blox.com>) to ensure that your GNSS device, firmware and the u-center software are the latest versions.
- Refer to our web based information service.

Worldwide Web

Our website (www.u-blox.com) is a rich pool of information. Product information and technical documents can be accessed 24/7.

By email

If you have technical problems or cannot find the required information in the provided documents, contact the closest technical support office. To ensure that we process your request as soon as possible, use our service pool email addresses rather than personal staff email addresses. Contact details are at the end of the document.

Helpful information when contacting technical support

When contacting technical support, have the following information ready:

- Receiver type (e.g. NEO-7N), firmware version (e.g. 1.00), and u-center release (e.g. u-center 8.00)
- Receiver configuration and short description of the application
- Your complete contact details

Contents

| | |
|--|-----------|
| Preface | 3 |
| Overview | 3 |
| Using this guide..... | 3 |
| Technical support | 3 |
| Contents..... | 4 |
| 1 Features | 6 |
| 2 Getting started | 7 |
| 2.1 General information about displayed values | 7 |
| 2.2 Connecting a u-blox evaluation kit to the PC | 7 |
| 2.3 Installing u-center | 7 |
| 2.4 Connect to the receiver | 8 |
| 2.4.1 Select the port..... | 8 |
| 2.4.2 Select the baud rate (only for COM ports) | 8 |
| 3 Concept and philosophy | 9 |
| 3.1 Color and satellite coding scheme | 10 |
| 3.2 Operating modes..... | 13 |
| 3.2.1 Online mode | 13 |
| 3.2.2 Stop mode | 13 |
| 3.2.3 Recorder mode..... | 13 |
| 3.2.4 Player mode | 13 |
| 3.2.5 Relations between modes..... | 14 |
| 3.3 Database limitation..... | 14 |
| 4 u-center menus and windows | 15 |
| 4.1 Main frame and toolbars | 15 |
| 4.1.1 Standard menu bar | 15 |
| 4.1.2 Standard toolbar | 36 |
| 4.1.3 Views toolbar | 36 |
| 4.1.4 Communication toolbar | 36 |
| 4.1.5 Log file toolbar | 37 |
| 4.1.6 Action toolbar | 37 |
| 4.1.7 Standard status bar | 37 |
| 4.2 Views and windows..... | 38 |
| 4.2.1 Packet console..... | 38 |
| 4.2.2 Binary console | 40 |
| 4.2.3 Text console | 41 |
| 4.2.4 Messages View..... | 55 |
| 4.2.5 Statistic view | 59 |

| | | |
|----------|--|-----------|
| 4.2.6 | Table view | 60 |
| 4.2.7 | Map view | 62 |
| 4.2.8 | Chart view..... | 72 |
| 4.2.9 | Histogram view | 75 |
| 4.2.10 | Camera view | 77 |
| 4.2.11 | Deviation map | 78 |
| 4.2.12 | Sky view | 80 |
| 5 | Tools..... | 83 |
| 5.1.1 | Firmware Update u-blox 5 - 8... .. | 83 |
| 5.1.2 | Dump receiver diagnostics..... | 84 |
| 5.1.3 | GNSS configuration | 85 |
| 5.1.4 | Hotkeys..... | 86 |
| 5.1.5 | Preferences..... | 86 |
| 6 | How To..... | 87 |
| 6.1 | Change baud rate of receiver | 87 |
| 6.2 | Save parameters to receiver non-volatile memory (BBR/Flash)..... | 88 |
| 6.2.1 | Saving parameters with UBX-CFG-CFG | 88 |
| 6.2.2 | Saving parameters with GNSS configuration..... | 88 |
| 6.3 | Recording/playing a log file..... | 88 |
| 6.4 | Conduct sensitivity tests | 89 |
| 6.5 | Read/write configuration files | 89 |
| 6.6 | Set GNSS system configuration..... | 89 |
| 6.7 | Activating PPP (EVK-6PPP only) | 90 |
| 6.8 | Change Epoch Detection Method..... | 91 |
| 7 | Troubleshooting | 92 |
| | Related documents..... | 93 |
| | Revision history | 93 |
| | Contact..... | 94 |

1 Features

u-center evaluation software provides system integrators and end users with a quick and simple way to interface with u-blox GNSS chipsets, modules and boards. It enables easy evaluation, performance testing, development and debugging of GNSS positioning chips and modules. u-center allows easy connection to u-blox products and provides a suite of features to view, log, and analyze performance. The features include:

- Support for u-blox's receivers using u-blox positioning technology. u-center can communicate with these receivers using either the UBX protocol or the NMEA-0183 standard protocol.
- Support for receivers that utilize standard NMEA strings.
- u-center presents all the information collected during the operation of the GNSS device. All aspects of GNSS data (position, velocity, time, satellite tracking, etc.) can be monitored and logged under various test scenarios for the evaluation of a receiver. u-center software allows analysis of the collected data in order to investigate performance issues such as accuracy, road test position and trajectory, satellite tracking, time to first fix, etc. All processed data can be captured in ASCII format and ported into popular spreadsheets for creating additional plots and statistics.
- Camera View: photographic data can be stored in the log file together with the navigation data and later be replayed in the application.
- Export data files to Google Earth and Google Maps.
- Supports (Multiple GNSS) AssistNow Online and AssistNow Offline.
- Data recording and playback function.
- Structural and graphical data visualization in real-time.
- Export functionality to standard PC applications.
- Docking views (real-time cockpit instruments):
Satellite constellation, compass, clock, altimeter, speedometer, GNSS and satellite information views.
- Download firmware updates to GNSS positioning modules.

2 Getting started

2.1 General information about displayed values

- Longitude and latitude are displayed according to the datum selected in the GNSS device (usually: WGS-84). This option can be polled and set using the UBX-CFG-DAT message.
- Time is displayed with reference to UTC.
- Elevation is displayed with reference to either MSL (Height above mean sea level or Orthometric Height) or to HAE (Height above WGS-84 ellipsoid). The reference is controlled by the GNSS configuration.


2.2 Connecting a u-blox evaluation kit to the PC

This section assumes that you have purchased a u-blox evaluation kit. Should you try to connect a different GNSS device to the PC, make sure you use appropriate RS-232 level shifters.

The evaluation kit can be connected to the PC by using either an USB or a serial cable. In case of using the USB port, a driver is required (contained in the u-center installer or downloadable from our homepage). Be sure to install the driver **before** connecting the evaluation kit to the computer.

2.3 Installing u-center

The installation program guides you through the necessary steps for a successful program installation. During the installation, you can choose the destination folder for the program.

 **u-center uses dynamic link libraries (DLL). The installation program will automatically install the required DLLs into the u-center program directory. Should you try to copy a u-center installation from one location to another after the installation, make sure you copy the DLL files as well.**

After a successful installation, u-center can be started from the Start Menu (All Programs → u-blox → u-center → u-center) and will start up as shown in Figure 1.








Figure 1: Start display

2.4 Connect to the receiver

2.4.1 Select the port

Locate the communication toolbar (Figure 2) and click on the arrow beside the  icon. This will show a list with all available COM ports (Figure 3). Select the corresponding COM port where the receiver is connected. If a link could be established, the icon will turn green  and the text in the status bar changes from  **Disconnected** to  **COM6 9600** (in this example u-center is connected to COM6). This does not mean that the communication already works but only that the port could be opened.




Figure 2: Communication toolbar






Figure 3: List of available COM ports

2.4.2 Select the baud rate (only for COM ports)

Again in the communication toolbar, click on the arrow beside the  icon. This will show a list with all available baud rates (Figure 4). Select the correct baud rate on which the receiver is communicating (typically 9600 baud). If u-center is able to decode data from the receiver, the status bar begins to blink in green as shown in the following icon:  **COM6 9600**. This means that the connection is established successfully and the communication between the receiver and u-center is working.




Figure 4: List of available baud rates

You are now ready to use the receiver.

3 Concept and philosophy

Understanding the basic concept behind u-center is important in order to get the highest benefit out of this powerful evaluation software. Figure 5 depicts the architecture of the software. The program gets a data stream from either a COM port or a log file and splits this stream into protocol messages. From the messages, relevant parameters are extracted and inserted into the current dataset of the database.

In the current dataset, statistical values of the parameters are calculated. Average, Minimum, Maximum and Standard Deviation are calculated for most parameters. If a protocol does not provide a parameter, u-center tries to calculate the parameter from the ones that are available. For example if velocity-north and velocity-east are available, u-center calculates the speed over ground and course over ground, unless this data is already available in the protocol.




Figure 5: Engine Architecture

When a new epoch (change in time) is detected, the current dataset is stored as history in the database. This history has a limited size. If the size is exceeded u-center keeps only the latest datasets and the oldest ones are removed. The history size may be adjusted. Refer to section 5.4 for the details

u-center provides various view classes for observation. Most views take their data from the database, but some get their data directly from the message without using the database at all. The other views are updated when the database changes.

- **Message Views** Displays and decodes a copy of every known message. This view allows observing a single message in detail and it may also be used to configure the GNSS device. Refer to Section 28.1.2 for details. The configuration view is a subset of the message view and only displays message to configure the receiver.

- **Console Views** Displays the messages in text form. They are particularly useful for users to develop GNSS firmware code. There is also a wide range of information available which is useful for evaluation and testing. Refer to sections 6.2.1, 6.2.2 and 6.2.3 for details.
- **Graphical Views** Displays parameters from the database in graphical form. Charts (see section 34.2.9), Histograms (section 34.2.10) and a Map Overlay (section 32.1.4) can be created. There are two more views (Deviation View and Sky View, see sections 34.2.12 and 35.1.1) that may be used for statistical performance and antenna pattern analysis.
- **Tabular Views** Shows the parameters of the database in tabular form. They can be freely configured to allow customized tables. Refer to sections 32.1.2 and 32.1.3 for details.
- **Docking Windows** Can be docked to the frame of u-center. An analog watch, compass, world map, altitude and speed meter are available. There are also docking windows showing the current signal power and the constellation of the satellites received by the device as well as a summary of the GNSS status.



Displaying various views and docking windows requires computing power. Minimizing or closing them may significantly reduce CPU usage.

3.1 Color and satellite coding scheme

In the graphical views and some docking windows, colors are used to indicate data quality. Table 1 shows the color codes for graphical views depending on the quality of the navigation solution.








| Color | | Meaning |
|---|---------|--|
|  | Yellow | Current value |
|  | Orange | Valid 3D navigation fix + Dead Reckoning |
|  | Green | Valid 3D navigation fix |
|  | Cyan | Valid 2D navigation fix |
|  | Magenta | Dead Reckoning Fix |
|  | Blue | Degraded navigation fix |
|  | Red | No or invalid navigation fix |

Table 1: Color-coding scheme for graphical views

Table 2 gives the color-coding scheme for the Docking Windows and Sky View. It indicates the state of each satellite.







| Color | Meaning | |
|---|----------------|---|
|  | Green | Satellite used in navigation (with Ephemeris) |
|  | 4 Olive | 5 Satellite used in navigation (with Ephemeris and PPP) |
|  | 5.1 Dark Green | 5.2 Satellite used in navigation (with aiding data: AssistNow Autonomous, AssistNow Online/Offline) |
|  | 5.2.1 Cyan | 5.2.2 Satellite signal available, available for use in navigation |
|  | 5.2.2.1 Blue | 5.2.2.2 Satellite signal available, not available for use in navigation |
|  | 5.2.2.2.1 Red | 5.2.2.2.2 Satellite signal not available |

Table 2: Color-coding scheme for the docking windows and sky view

Table 3 gives the satellite-coding scheme for the docking windows and sky view.

| Satellite Code | System |
|----------------|---------|
| Gxx | GPS |
| Rxx | GLONASS |
| Bxx | BeiDou |
| Exx | Galileo |
| Sxx | SBAS |
| Qxx | QZSS |

Table 3: Satellite-coding scheme for the docking windows and sky view

Figure 6 shows the color legend. This is available under: Tools → Preferences → Status Colors.




Figure 6: Color-coding scheme for graphical views, docking windows, and sky view

5.3 Operating modes

u-center has different operating modes (see Figure 7). The mode changes when you open or close a log file or when you make an action in the player. To be able to use the record mode you have to create a new file, save to a new file or open an existing file. The record and player mode are only available if you have created a new file or when you have opened a write-able file.




Figure 7: Relations between operating modes

5.3.1 Online mode

In this mode a GNSS device is directly connected to u-center via a COM port. u-center can control and configure the receiver and it will display the data that the receiver is sending periodically.

5.3.2 Stop mode

In this mode no data from a receiver or a log file is forwarded to the database and views. u-center is in this mode when a log file is open but player and recorder are not active.

5.3.3 Recorder mode

Recorder Mode is the same mode as the Online Mode, except u-center additionally creates a log file, concatenating all the messages sent by the receiver. You enter this mode by creating a new log file or opening an existing log file without write protection and pressing the record button. An example of using this mode would be to make overnight measurements and evaluate the data at a later time. u-blox customer support may request a log file from you when you are experiencing a problem with one of our receivers.

5.3.4 Player mode

The Player Mode allows replaying a previously recorded log file step by step, in real-time or at an accelerated rate. You enter this mode by opening a file and pressing the play, step or scan button.

5.3.5 Relations between modes

The operating mode depends on the status of the log file player. Modes are changed by user actions. Each mode has different states that are changed by a user action or by an event (see Figure 7).

In **Online** and **Recorder** modes, u-center displays data from the receiver. In **Player** mode data from a log file is displayed. Player mode has different states. In **Play** state messages are read and displayed periodically from the log file. The very intuitive user interface is derived from that of a CD player. u-center updates the views after each message. **Step** state only gets one message from the log file and immediately returns to paused **Play** state. **Scan** state also reads messages periodically but the display is only updated when paused or by changing the state. Position can be set in a log file. This behaves differently in the Player and Stop modes. In Stop mode the position is just set and no data is read and displayed. u-center will start recording or playing from that position when changing the mode. If position is set in **Player** mode, u-center will load the data up to this position from the log file and display the contents.

5.4 Database limitation

The number of epochs displayed in u-center is limited in order to allow an efficient analysis of large log files. The limit is set to 1800 epochs by default. This means if an epoch is available every second you can analyze data for up to 30 minutes. After this time the oldest values are discarded. Data stored to a log file is not affected by the database limitation.




Figure 8: Set maximum number of epochs to keep in database



For long-term observations, it's recommended to start recording a log file before analysis begins.



If a high value of epochs is selected, the display of data in real-time cannot be guaranteed, especially when graphical views are open.

6 u-center menus and windows

6.1 Main frame and toolbars

The main frame is the primary display screen of u-center. It displays all tool bars and some of the information provided by the device. In the standard status bar, information about communication, UTC time, connection time, used protocol (NMEA or UBX), used file, etc. is shown.

- **Button tool tip:** A description about each button in the toolbars can be obtained by holding the mouse cursor over the button for a few seconds. A tool tip message will appear near the icon with additional information while a detailed description is displayed in the status display.




Figure 9: u-center main frame and toolbars

6.1.1 Standard menu bar

All u-center functions can be accessed through the standard menu bar. Commands can also be accessed by shortcuts that are listed in the menus. Some often used operations are also available in the different toolbars.

6.1.1.1 File




Figure 10: File menu entries

| Function | Description | Shortcut / Toolbar icon |
|----------|-------------|-------------------------|
|----------|-------------|-------------------------|








| | | |
|------------------------|--|--|
| New... | Creates a new log file. No data is yet written but only the file is opened. The duration of the logging time is displayed in the status bar field Operating time. | Ctrl+N /  |
| Save... | Creates a new log file, saves the data from the internal database to the log file and starts immediately recording all new data from the receiver. This is useful when an error or an unexpected event occurred and no log file was recorded. The size of the ring buffer (4 MB) is large enough to retain the data for the last hour (approx.). | Ctrl+S /  |
| Open... | Opens a stored log file to be replayed. | Ctrl+O |
| Close | Closes the active file. | Ctrl+E /  |
| Database Empty | Deletes the internal database and all saved values. |  |
| Database Export | Exports the internal database into HTML or KML data formats for displaying with Google Map or Google Earth. | |
| Print... | Prints the active document. |  |
| Print Preview | Shows a preview of the print output. |  |
| Print Setup... | Shows the setup dialog of the printer. | |
| Recent Files | Lists all recently used files. |  |
| Exit | Exits u-center. | |

Table 4: File menu entries

6.1.1.2 Edit

| | |
|------------|----------|
| Cut | Ctrl+X |
| Copy | Ctrl+C |
| Paste | Ctrl+V |
| Delete | Del |
| Select All | Ctrl+A |
| Clear All | Ctrl+Del |

Figure 11: Edit menu entries

| Function | Description | Shortcut / Toolbar icon |
|----------|-------------|-------------------------|
|----------|-------------|-------------------------|




| | | |
|-------------------|---|---|
| Cut | Cut the current selection and put in to the clipboard | Ctrl+X / Shift+Del /  |
| Copy | Copy the current selection to the clipboard | Ctrl+C / Ctrl+Insert /  |
| Paste | Paste the clipboard content to the current position | Ctrl+V / Shift+Insert /  |
| Delete | Delete the current selection | Del |
| Select All | Select all in the current view | Ctrl+A |
| Clear All | Clear all in the current view | Ctrl+Del |

Table 5: Edit menu entries

The Edit menu is fully Microsoft Windows compliant.

6.1.1.3 View
























Figure 12: View menu entries

| Function | Description | Shortcut / Toolbar icon |
|----------|-------------|-------------------------|
|----------|-------------|-------------------------|

| | | |
|--------------------------------|--|---|
| Packet Console | Opens the packet console. | F6 /  |
| Binary Console | Opens the binary console. | F7 /  |
| Text Console | Opens the text console. | F8 /  |
| Messages View | Opens the dialog with all supported messages. | F9 /  |
| Configuration View | Opens the dialog with all configuration messages. This is a subset of the Messages View. | Ctrl+F9 /  |
| Statistic View | Opens the statistic view with all data from the internal database. | F10 /  |
| Table View | Opens the empty table view. All values from the internal database can be displayed individually. | F11 /  |
| Recent Table Views | Lists all the table views that have been opened. This information comes from the Windows registry and is also valid after a restart of u-center. | |
| Map View | Opens a window allowing to display a map. |  |
| Recent Map Views | Lists all the maps views that have been opened. This information comes from the Windows registry and is also valid after a restart of u-center. | |
| Chart View | Opens a window with chart functionality. All values from the internal database can be displayed individually. |  |
| Recent Chart View | Lists all the chart views that have been opened. This information comes from the Windows registry and is also valid after a restart of u-center. | |
| Histogram View | Opens a window with histogram functionality. All values from the internal database can be displayed individually. |  |
| Recent Histogram View | Lists all the histogram views that have been opened. This information comes from the Windows registry and is also valid after a restart of u-center. | |
| Camera View | Opens a window allowing to connect to a webcam and visualize and save the image. | |
| Deviation Map | Opens a window with a position deviation map. | F12 /  |
| Sky View | Opens a window with the sky view. The current position of the satellites and their values from the internal database are shown. |  |
| Docking Windows | Opens a list with all available docking windows that can be shown. | |
| Satellite Position | Shows or hide the current satellite positions. | |
| Satellite Level | Shows or hide the current satellite levels. |  |
| Satellite Level History | Shows or hide the history of the satellite levels. |  |
| World Position | Shows or hide the current position on the world map. |  |
| Data | Shows or hide data from the navigation solution (like position, TTFF, accuracy and DOPs) |  |
| Altitude Meter | Shows or hide the altitude meter. |  |
| Compass | Shows or hide the compass. |  |
| Speed Meter | Shows or hide the speed meter. |  |
| Watch | Shows or hide the clock. |  |
| Toolbars | Opens a list with all available toolbars that can be shown. | |

| | |
|----------------------------------|--|
| Standard Toolbar | Shows or hide the standard toolbar. |
| Views Toolbar | Shows or hide the views toolbar. |
| Receiver Toolbar | Shows or hide the receiver toolbar. |
| Player Toolbar | Shows or hide the player toolbar. |
| Action Toolbar | Shows or hide the action toolbar. |
| AssistNow Offline Toolbar | Shows or hide the AssistNow Offline toolbar. |

Table 6: View menu entries

6.1.1.4 Player




Figure 13: Player menu entries

| Function | Description | Shortcut / Toolbar icon |
|----------|-------------|-------------------------|
|----------|-------------|-------------------------|

| | | |
|-------------------|--|--------------|
| Eject | Closes the active log file | Ctrl+E / |
| Stop | Stops reading or recording from the active log file | Ctrl+H / |
| Pause | Pauses reading or recording from the active log file. | Ctrl+P / |
| Record | Starts recording to a new or already opened log file. Any data in the internal database will not be written to the file. If you want to save this data into a log file, open the File menu and click Save. | Ctrl+R / |
| Step | Single step function. The next message is read. | Ctrl+Space / |
| Play | Starts reading from the active log file. The speed of the action can be chosen on the sub-menu. | Ctrl+G / |
| Scan | Reads the entire log file into the database and updates the display at the end of the scan period | Ctrl+F / |
| Goto Begin | Sets the read position to the begin of the log file | |
| Goto End | Sets the read position to the end of the log file | |

Table 7: Player menu entries

6.1.1.5 Receiver















Figure 14: Receiver menu entries

| Function | Description | Shortcut / Toolbar icon |
|----------|-------------|-------------------------|
|----------|-------------|-------------------------|

| | | |
|---------------------------|---|---|
| Port | Defines the port u-center connects to. The list is generated automatically using the enumeration method under Tools → Preferences → Generic Enumerate serial ports using. The currently used port will be indicated with a  . |  |
| Disconnect | Disconnects from a connected receiver | |
| COM [1...9] | Connects to COM[1...9] with the current baud rate. | Ctrl+[1...9] |
| Network connection | Connects to a receiver through network. | |
| Baud rate | Defines the baud rate of the communication. The list is pre-defined and cannot be changed. The currently set baud rate will be indicated with a  . |  |
| Location API | Connects to the receiver using the Location API | |
| Sensor API | Connects to the receiver using the Sensor API (the USB Sensor driver is required in this case) | |
| Autobauding | Enables or disables autobauding for the current communication with the receiver | |
| Debug Messages | Enables all debug messages in the receiver. Can be requested by the u-blox support. |  |
| Generation | Defines the generation of the attached u-blox GNSS receiver. u-center also tries to detect automatically the correct generation. | |
| Protocol Filter | Sets the message filter against versions of protocol specification. | |
| Action | Lists all possible actions that can be performed with the u-blox GNSS receiver. This includes the following: | |
| Hot start | Sends a hot start command to the receiver. No data is deleted in the receiver. |  |
| Warm start | Sends a warm start command to the receiver. Only the ephemeris are deleted from the memory. |  |
| Cold start | Sends a cold start command to the receiver. All information is deleted from the memory. |  |
| Save Config | Saves the current receiver configuration to the memory so that it will be loaded after a restart. |  |
| Load Config | Loads the last saved configuration from the memory. |  |
| Revert Config | Deletes all configurations in the memory and reverts the receiver to the default configuration. |  |

Differential DGNSS Interface... Allows the streaming of RTCM messages to the receiver for high precision applications.

Epoch detection... Defines which time information determines the boundary of an epoch detection in u-center.

Table 8: Receiver menu entries

6.1.1.6 Tools




Figure 15: Tools menu entries

Some of the menu items will only be displayed when the correct receiver generation is connected and identified by u-center. If you cannot select one option, change the receiver generation under Receiver → Generation.

| Function | Description | Shortcut / Toolbar icon |
|----------|-------------|-------------------------|
|----------|-------------|-------------------------|

Firmware Update u-blox 5 - 8...

Opens the firmware update dialog for u-blox 5 - 8 generation receivers. Ctrl+U

| | |
|--------------------------------------|--|
| Dump Receiver Diagnostics... | Tool to create the receiver diagnostic. Can be requested by the u-blox support team. |
| u-blox 7/8/M8 Retrieve Log... | Opens the dialog to download log information from the receiver. This is supported only since u-blox 7 receivers. |
| AssistNow Offline | Opens the AssistNow Offline dialog. Please switch over to AssistNow Offline as the legacy service is marked deprecated. |
| AssistNow Online | Opens the AssistNow Online dialog. Please switch over to AssistNow Online as the legacy service is marked deprecated. |
| GNSS Configuration... | Opens the dialog to save the receiver configuration to a file on the PC or to restore a configuration from a file on the PC. |
| File transfer... | Opens File Transfer to Receiver dialog |
| Preferences... | Opens the dialog for the u-center preferences. |

Table 9: Tools menu entries

6.1.1.7 Window




Figure 16: Window menu entries

| Function | Description | Shortcut / Toolbar icon |
|----------|-------------|-------------------------|
|----------|-------------|-------------------------|

| | |
|------------------------------------|--|
| Cascade | Arranges all open dialogs cascaded. |
| Tile Horizontally | Arranges all open dialogs horizontally. |
| Tile Vertically | Arranges all open dialogs vertically. |
| Close All | Closes all open dialogs and windows. |
| Save Workspace As... | Allows to save the position of the open dialogs and windows to a file on the computer. |
| Restore Workspace From... | Allows to restore the position of the dialogs and windows from a file on the computer. |
| Recent Workspace | Lists all recently used workspace files. |
| Arrange Icons | Arranges the icons at the bottom of the window. |
| List of dialogs and windows | Lists all visible and hidden dialogs and windows in u-center. |

Table 10: Window menu entries

6.1.1.8 Help




Figure 17: Helpmenu entries

| Function | Description | Shortcut / Toolbar icon |
|----------|-------------|-------------------------|
|----------|-------------|-------------------------|

| | | |
|--------------------|--------------------------------|----|
| Contents... | References to this user guide. | F1 |
|--------------------|--------------------------------|----|

| | |
|--------------------------|---|
| About u-center... | Shows the about dialog with the software version and the used libraries and their versions. |
|--------------------------|---|

Table 11: Help menu entries

6.1.2 Standard toolbar

The standard toolbar gives access to standard operations like opening and saving files, print the current view or empty the database.




Figure 18: Standard toolbar entries

6.1.3 Views toolbar




Figure 19: Views toolbar entries

6.1.4 Communication toolbar




Figure 20: Communication toolbar entries

6.1.5 Log file toolbar




Figure 21: Log file toolbar entries

6.1.6 Action toolbar




Figure 22: Action toolbar entries

6.1.7 Standard status bar

The standard status bar is updated automatically and shows the information about the opened file, the connection and the time.

The following fields are available:

Status display: Displays the current action or the function of a button if the mouse cursor is over the button


DGNSS information: Shows the connection to a DGNSS source (only when activated through Receiver → Differential GNSS Interface...)

Receiver generation: u-center tries to automatically detect the type of device connected and activates the appropriate mode of operation in order to take optimal advantage of the features. The mode can also be manually selected through the menu bar (Receiver → Generation).


Port information: Shows the active COM port and baud rate.



Color coding of the icon:

 Disconnected

 Waiting for first data

 Data is being received but errors are detected (mostly because of wrong baud rate settings)

 Last data received was valid but there is no data to collect at this time

-  No data is being received but errors have been detected in the past
-  Data is being received and collected at the correct baud rate

File: As soon as a file is used (this file must first be opened) the name of the file will be displayed (xxxxxx.ubx).




Protocol information: This box indicates the current message set that is being used to communicate with the device. This can be the NMEA-0183 standard or the UBX protocol. The UBX protocol provides more extensive information with the receiver. u-center can handle both protocols.

Operating time: The time elapsed since you started u-center.

UTC time: The current time sent by the device. This field is only updated if a receiver is connected.

Receiver status: Shows the last known status of the receiver

Color coding of the icon:

-  Power status of receiver is unknown
-  Receiver is powered on
-  Receiver is powered off

6.2 Views and windows

6.2.1 Packet console

The packet console lists all incoming and outgoing messages, and provides information about message length and type. The direction of the message is shown in the following way:-

- R <- Indicates the message was sent to the receiver
- R -> Indicates the message came from the receiver




Figure 23: Packet console

Refer to Table 12 for an explanation of the icons and text fields.

6.2.2 Binary console

The binary console lists all incoming messages in binary and ASCII format.




Figure 24: Binary console

Refer to Table 12 for an explanation of the icons and text fields.

6.2.3 Text console

The text console displays the content messages in textual form such as UBX-INF or NMEA messages.

NMEA messages are shown with heading \$Gxyyy, where x stands for the satellite system (P = GPS, SBAS, QZSS, L = GLONASS, A = Galileo, B = BeiDou, N = Any combination of GNSS) and yyy for the type of message (e.g. ZDA=Time & Date).




Figure 25: Text console displaying UBX-INF and NMEA messages. Last part has "Show PC Time" enabled






| Element | Name | Description |
|---|-------------------|---|
|  | Lock / Locked | Prevents the console from being updated with new data when locked. Pause key can be used to Lock/Unlock the current console window. |
|  | Clear All | Erases all data in the console |
|  | Show/Hide PC time | Shows/Hides the PC time in the console. See Figure 25 for an example. |
| 6.2.4  | Filter On/Off | Filters unwanted data from the data stream. This allows searching for certain expression, e.g. all RMC messages (). |
|  | Pause player | Pauses the player when the search expression is found. Only works in playback mode. |

Table 12: Description of the buttons of the console views

6.2.4.1 Regular expression evaluation

Normally, when you search for a sub-string in a string, the match should be exact. So if we search for a sub-string "abc" then the string being searched should contain these exact letters in the same sequence for a match to be found. We can extend this kind of search to a case insensitive search where the sub-string "abc" will find strings like "Abc", "ABC" etc. That is, the case is ignored but the sequence of the letters should be exactly the same. Sometimes, a case insensitive search is also not enough. For example, if we want to search for numeric digit, then we basically end up searching for each digit independently. This is where regular expressions come in to our help. Regular expressions are text patterns that are used for string matching. Regular expressions are strings that contain a mix of plain text and special characters to indicate what kind of matching to do. Here's a very brief tutorial on using regular expressions.

Suppose, we are looking for a numeric digit then the regular expression we would search for is "[0-9]". The brackets indicate that the character being compared should match any one of the characters enclosed within the bracket. The dash (-) between 0 and 9 indicates that it is a range from 0 to 9. Therefore, this regular expression will match any character between 0 and 9, that is, any digit. If we want to search for a special character literally we must use a backslash before the special character. For example, the single character regular expression "*" matches a single asterisk. In the table below the special characters are briefly described. A regular expression search is case sensitive.

| 7 | Character | 8 | Description |
|---|-----------|---|-------------|
|---|-----------|---|-------------|

| 7 | Character | 8 | Description |
|---|-----------|----|---|
| 9 | ^ | 10 | Beginning of the string. The expression "^A" will match an "A" only at the beginning of the string. |

| 7 | Character | 8 | Description |
|----|-----------|----|--|
| 11 | [^ | 12 | The caret (^) immediately following the left-bracket ([) has a different meaning. It is used to exclude the remaining characters within brackets from matching the target string. The expression "[^0-9]" indicates that the target character should not be a digit. |

| 7 | Character | 8 | Description |
|----|-----------|----|---|
| 13 | \$ | 14 | The dollar sign (\$) will match the end of the string. The expression "abc\$" will match the sub-string "abc" only if it is at the end of the string. |

| 7 | Character | 8 | Description |
|----|-----------|----|--|
| 15 | | 16 | The alternation or logic OR character () allows either expression on its side to match the target string. The expression "a b" will match "a" as well as "b". |

| 7 | Character | 8 | Description |
|----|-----------|----|---------------------------------------|
| 17 | . | 18 | The dot (.) will match any character. |

| 7 | Character | 8 | Description |
|----|-----------|----|---|
| 19 | * | 20 | The asterisk (*) indicates that the character to the left of the asterisk in the expression should match 0 or more times. |

| 7 | Character | 8 | Description |
|----|-----------|----|--|
| 21 | + | 22 | The plus (+) is similar to asterisk but there should be at least one match of the character to the left of the + sign in the expression. |

| 7 | Character | 8 | Description |
|----|-----------|----|---|
| 23 | ? | 24 | The question mark (?) matches the character to its left 0 or 1 times. |

| 7 | Character | 8 | Description |
|----|-----------|----|--|
| 25 | () | 26 | The parenthesis affects the order of pattern evaluation. |

| 7 | Character | 8 | Description |
|----|-----------|----|--|
| 27 | [] | 28 | Brackets ([and]) enclosing a set of characters indicates that any of the enclosed characters may match the target character. |

Table 13: Regular expression syntax

28.1.1.1 Example

Let's assume that the following lines would appear in the NMEA console without filtering.

```
14:00:03 $GPGGA,140003.242,4717.1126,N,00833.7862,E,1,06,1.3,543.0,M,,0000*09
14:00:03 $GPGLL,4717.1126,N,00833.7862,E,140003.242,A*34
14:00:03 $GPGSA,A,3,06,17,25,22,30,10,,,,,,,,,2.9,1.3,2.6*3A
14:00:03 $GPGSV,2,1,07,06,58,062,44,17,52,161,44,25,45,239,44,22,35,301,44*7F
14:00:03 $GPGSV,2,2,07,30,31,123,44,10,17,059,39,01,05,316,*4E
14:00:03 $GPRMC,140003.242,A,4717.1126,N,00833.7862,E,0.03,80.59,010201,,*36
14:00:03 $GPVTG,80.59,T,,M,0.03,N,0.1,K*56
14:00:04 $GPGGA,140004.242,4717.1126,N,00833.7862,E,1,06,1.3,542.0,M,,0000*0F
14:00:04 $GPGLL,4717.1126,N,00833.7862,E,140004.242,A*33
14:00:04 $GPGSA,A,3,06,17,25,22,30,10,,,,,,,,,2.9,1.3,2.6*3A
14:00:04 $GPGSV,2,1,07,06,58,062,45,17,52,161,44,25,45,239,44,22,35,301,44*7E
14:00:04 $GPGSV,2,2,07,30,31,123,44,10,17,059,39,01,05,316,*4E
14:00:04 $GPRMC,140004.242,A,4717.1126,N,00833.7862,E,0.02,152.96,010201,,*0D
14:00:04 $GPVTG,152.96,T,,M,0.02,N,0.0,K*6B
```

In the following examples the characters marked red match the regular expression.

Example 1: Searching for the RMC with a valid position and all GGA Messages

"GP (GGA | RMC, . *, A,) "

```
14:00:03 $GPGGA,140003.242,4717.1126,N,00833.7862,E,1,06,1.3,543.0,M,,0000*09
14:00:03 $GPRMC,140003.242,A,4717.1126,N,00833.7862,E,0.03,80.59,010201,,*36
14:00:04 $GPGGA,140004.242,4717.1126,N,00833.7862,E,1,06,1.3,542.0,M,,0000*0F
14:00:04 $GPRMC,140004.242,A,4717.1126,N,00833.7862,E,0.02,152.96,010201,,*0D
```

Example 2: Searching for all GSV with the message index of "2" or "3"

"GSV, . *, [2-3] , "

```
14:00:03 $GPGSV,2,2,07,30,31,123,44,10,17,059,39,01,05,316,*4E
114:00:04 $GPGSV,2,2,07,30,31,123,44,10,17,059,39,01,05,316,*4E
```

Example 3: Searching for all messages starting with \$GP, which have a "G" in the message identifier but not at the first position

"^\\\$GP.+G.*, "

```
14:00:03 $GPGGA,140003.242,4717.1126,N,00833.7862,E,1,06,1.3,543.0,M,,0000*09
14:00:03 $GPVTG,80.59,T,,M,0.03,N,0.1,K*56
14:00:04 $GPGGA,140004.242,4717.1126,N,00833.7862,E,1,06,1.3,542.0,M,,0000*0F
14:00:04 $GPVTG,152.96,T,,M,0.02,N,0.0,K*6B
```

Example 4: Searching for all message having a checksum of which the higher nibble is 3

"*3.\$"

```
14:00:03 $GPGLL,4717.1126,N,00833.7862,E,140003.242,A*34
14:00:03 $GPGSA,A,3,06,17,25,22,30,10,,,,,,,,,2.9,1.3,2.6*3A
14:00:03 $GPRMC,140003.242,A,4717.1126,N,00833.7862,E,0.03,80.59,010201,,*36
14:00:04 $GPGLL,4717.1126,N,00833.7862,E,140004.242,A*33
14:00:04 $GPGSA,A,3,06,17,25,22,30,10,,,,,,,,,2.9,1.3,2.6*3A
```


28.1.2 Messages View

The messages view is utilized to communicate with the device. Receiver output messages (e.g. navigation output, status and debug information) are displayed; input messages (e.g. configuration messages) can be sent. There are different sections for NMEA and UBX protocol.




Figure 26: Message View

| | | | | | |
|----|---------|----|------|----|-------------|
| 29 | Element | 30 | Name | 31 | Description |
|----|---------|----|------|----|-------------|







| | | | |
|----|---|----------------|---|
| 32 |  | Lock / Locked | Prevents the message view from being updated with new data when locked. Pause key can be used to Lock/Unlock the current view window. |
| |  | Clear All | Erases the entire message view. |
| |  | Send | Sends the current message to the device. |
| |  | Poll | Polls the selected message once. |
| |  | Auto poll | Automatically polls a newly selected message once |
| |  | Message Hotkey | Assigns a hotkey to the selected message |

Table 14: Description of the buttons in the messages view toolbar

32.1.1.1 Receiver output messages

Message tree
 Black text indicates that the message was received in the last second.
 Grey text means that the message was never received or no new data is available.

| Parameter | Value | Unit | Description |
|--------------------|-------------|------------|--|
| UTC | 074353.00 | hhmmss.sss | Universal time coordinated |
| Lat | 4717.11213 | ddmm.mmmm | Latitude |
| Northing Indicator | N | | N=North, S=South |
| Lon | 00833.91480 | dddmm.mmmm | Longitude |
| Easting Indicator | E | | E=East, W=West |
| Status | 2 | | 0=Invalid, 1=2D/3D, 2=DGPS, 6=Dead Reckoning |
| SVs Used | 12 | | Number of SVs used for Navigation |
| HDOP | 0.60 | | Horizontal Dilution of Precision |
| Alt (MSL) | 501.7 | m | Altitude (above means sea level) |
| Unit | M | | M=Meters |
| Geoid Sep. | 47.3 | m | Geoid Separation = Alt(HAE) - Alt(MSL) |
| Unit | M | | M=Meters |
| Age of DGPS Corr | | s | Age of Differential Corrections |
| DGPS Ref Station | 0000 | | ID of DGPS Reference Station |

Message Content

```
0000 24 47 4E 47 47 41 2C 30 37 34 33 35 33 2E $GNGGA,074353.
000E 30 30 2C 34 37 31 37 2E 31 31 32 31 33 2C 00,4717.11213,
001C 4E 2C 30 30 38 33 33 2E 39 31 34 38 30 2C N,00833.91480,
002A 45 2C 32 2C 31 32 2C 30 2E 36 30 2C 35 30 E,2,12,0.60,50
0038 31 2E 37 2C 4D 2C 34 37 2E 33 2C 4D 2C 2C 1.7,M,47.3,M,,
0046 30 30 30 30 2A 34 38 0D 0A 0000*4838
```

Hex Dump

Figure 27: Message display of an output message



Double-clicking on an output message enables or disables the periodic message update if the communication protocol is active. This feature is currently only supported for the UBX protocol.


32.1.1.2 Receiver input messages

Input messages can be edited and sent to the device from the messages view. It is also possible to poll the current receiver settings.



u-center performs some range checks on input messages. If an input value exceeds the permitted range, u-center will highlight the field in red but it is still possible to send the value to the receiver. However, the receiver is likely to reject such a message.




32.1.3 Table view



| Index | UTC | Lat | Lon | Alt (HAE) | PACC 3D | VDOP |
|-------|-------------------------|-----------|----------|-----------|---------|------|
| 231 | 08:07:42.000 12/09/2013 | 47.285219 | 8.565248 | 550.60 | | 1.1 |
| 232 | 08:07:43.000 12/09/2013 | 47.285219 | 8.565249 | 550.60 | | 1.1 |
| 233 | 08:07:44.000 12/09/2013 | 47.285219 | 8.565249 | 550.50 | | 1.1 |
| 234 | 08:07:45.000 12/09/2013 | 47.285219 | 8.565249 | 550.50 | | 1.1 |
| 235 | 08:07:46.000 12/09/2013 | 47.285219 | 8.565250 | 550.40 | | 1.1 |
| 236 | 08:07:47.000 12/09/2013 | 47.285219 | 8.565250 | 550.30 | | 1.1 |
| 237 | 08:07:48.000 12/09/2013 | 47.285219 | 8.565250 | 550.20 | | 1.1 |
| 238 | 08:07:49.000 12/09/2013 | 47.285219 | 8.565251 | 550.10 | | 1.1 |
| 239 | 08:07:50.000 12/09/2013 | 47.285219 | 8.565251 | 550.10 | | 1.1 |
| 240 | 08:07:51.000 12/09/2013 | 47.285219 | 8.565251 | 550.10 | | 1.1 |
| 241 | 08:07:52.000 12/09/2013 | 47.285219 | 8.565251 | 550.00 | | 1.1 |
| 242 | 08:07:53.000 12/09/2013 | 47.285219 | 8.565251 | 550.00 | | 1.1 |
| 243 | 08:07:54.000 12/09/2013 | 47.285219 | 8.565252 | 550.00 | | 1.1 |
| 244 | 08:07:55.000 12/09/2013 | 47.285219 | 8.565252 | 549.90 | | 1.1 |
| 245 | 08:07:56.000 12/09/2013 | 47.285219 | 8.565253 | 549.80 | | 1.1 |
| 246 | 08:07:57.000 12/09/2013 | 47.285219 | 8.565253 | 549.80 | | 1.1 |
| 247 | 08:07:58.000 12/09/2013 | 47.285218 | 8.565253 | 549.80 | | 1.1 |
| 248 | 08:07:59.000 12/09/2013 | 47.285218 | 8.565254 | 549.80 | | 1.1 |
| 249 | 08:08:00.000 12/09/2013 | 47.285217 | 8.565254 | 549.80 | | 1.1 |
| 250 | 08:08:01.000 12/09/2013 | 47.285217 | 8.565254 | 549.80 | | 1.1 |
| 251 | 08:08:02.000 12/09/2013 | 47.285217 | 8.565254 | 549.70 | | 1.1 |
| 252 | 08:08:03.000 12/09/2013 | 47.285216 | 8.565254 | 549.70 | | 1.1 |
| 253 | 08:08:04.000 12/09/2013 | 47.285216 | 8.565254 | 549.60 | | 1.1 |
| 254 | 08:08:05.000 12/09/2013 | 47.285216 | 8.565254 | 549.60 | | 1.1 |
| 255 | 08:08:06.000 12/09/2013 | 47.285216 | 8.565254 | 549.50 | | 1.1 |
| 256 | 08:08:07.000 12/09/2013 | 47.285216 | 8.565254 | 549.50 | | 1.1 |
| 257 | 08:08:08.000 12/09/2013 | 47.285216 | 8.565254 | 549.50 | | 1.1 |
| 258 | 08:08:09.000 12/09/2013 | 47.285216 | 8.565254 | 549.50 | | 1.1 |
| 259 | 08:08:10.000 12/09/2013 | 47.285216 | 8.565254 | 549.50 | | 1.1 |
| 260 | 08:08:11.000 12/09/2013 | 47.285216 | 8.565254 | 549.50 | | 1.1 |
| 261 | 08:08:12.000 12/09/2013 | 47.285216 | 8.565254 | 549.60 | | 1.1 |
| 261 | 08:08:12.000 12/09/2013 | 47.285216 | 8.565254 | 549.60 | | 1.1 |

Figure 29: Table view

All values from the database can be displayed in a tabular form (Figure 29). This is very useful when analyzing the log file in detail.

To add a new column, first select the desired value (Figure 30) and click the  button. To remove a displayed value, click the  button. To see the table header click the  button. Statistical information will be shown.

| | | | | | | |
|-----------|-------------------------|-----------|----------|--------|-------|-----|
| Unit | time date | * | * | m | m | |
| Count | 469 | 469 | 469 | 468 | 0 | 468 |
| Age | 0 | 0 | 0 | 0 | | 0 |
| Current | 08:11:39.000 12/09/2013 | 47.285213 | 8.565255 | 549.70 | | 1.1 |
| Minimum | 08:03:51.000 ??/??/???? | 47.285206 | 8.565244 | 549.00 | | 1.1 |
| Maximum | 08:11:39.000 12/09/2013 | 47.285220 | 8.565259 | 551.20 | | 1.1 |
| Average | | 47.285212 | 8.565253 | 550.20 | 0.000 | 1.1 |
| Deviation | | 0.000004 | 0.000004 | 0.50 | | 0.0 |





Figure 30: Selecting a new value

- ☞ The number of displayed epochs is set to 1800 by default (see also section 5.4).
- ☞ Choosing “Database Empy” in the file menu or pressing the button  clears the table view.
- ☞ The content of the table view can easily be exported to other programs using Copy/Paste.

32.1.4 Map view

u-center can display positions on pre-calibrated maps (Figure 31). This allows a basic analysis of road tests.



Figure 31: Map view

32.1.4.1 Using map view

You can access the view specific commands in two different ways:

- Using the command in the tool bar below the map view.
- Holding the cursor inside the map view and pressing the right mouse button will. This will open the following context menu (see Figure 33).




Figure 32: Map view context menu

| Function | Description | Shortcut / Toolbar icon |
|----------|-------------|-------------------------|
|----------|-------------|-------------------------|














| | | |
|---|--|---|
| Cursor | The position of the cursor is shown on the lower left edge of the u-center screen (Longitude, Latitude and Pixel-Position). By holding the left mouse button and moving the cursor over the map you can measure distance from one position to another |  |
| Move | The map inside the map view window can be moved |  |
| Zoom In | The map is enlarged by selecting a rectangle |  |
| Zoom Out | The size of the Map is decreased |  |
| Zoom Factor | Different specific zoom level can be selected |  |
| Fit Map | The map size is adjusted to fit the Map Window |  |
| Markers | Add or remove the defined markers (see also section 32.1.4.2, Map calibration) |  |
| Follow | Center the map on the current GNSS position |  |
| Drawing Mode | The size and form of the displayed position can be changed; the connection line between the points can be selected in the menu Connect. To see statically values (average, minimum, maximum, standard deviation) directly in the map, select the Menu Statistic. |  |
| Open Map... / Recent Maps | Load a new or one of 8 recently used maps. |  |
| Copy | | |
| Save map (only in toolbar) | The current display can be stored in different formats |  |
| Image settings (only in toolbar) | Brightness, contrast and color saturation of map can be adjusted by moving the glides |  |

Table 15: Description of the buttons and context menu entries in map view



Map Views can be copied to the clipboard using the "Print Screen" function.



Choosing "Database Empy" in the file menu or pressing the button  deletes all recently displayed positions and routes.

32.1.4.2 Map calibration

To create your own map you will need a digitized map or pictures with orthogonal projection in one of the following pixel graphics formats.

| | |
|-----------------|------------------------------|
| png | Portable Network Graphics, |
| bmp | Windows Bitmap |
| dib | Device Independent Bitmap |
| gif | Graphics Interchange Format |
| jpg/jpeg | Jpeg File Interchange Format |
| pcx | PC paintbrush |
| tif | Tag Image File Format |

If your map is not in one of the above formats, you can simply convert it in one of the supported formats by a third party program. u-blox provides two sample maps. Office.png is a small map of the surroundings of the u-blox headquarters. World.png is a map of the whole world but with limited resolution.

To use a map in u-center, three calibration points are needed. For these points you have to know the pixel coordinates and the according WGS84 coordinates in the latitude/longitude format in degrees (longitude: -180.0 to 180.0, latitude: -90.0 to 90.0). These points are stored in the map calibration file. The calibration file must be stored at the same location as the bitmap itself. It has the same name but a different extension (*.mcf). The format of the calibration file is very simple and can be edited in a simple editor like notepad.

Examples:

As an example we will have a closer look at the provided map "world.png" and its calibration file "world.mcf".




Figure 33: Digital map file: world.png

The Map has 1765 Pixels (0 to 1764) in the horizontal and 1046 Pixels (0 to 1045) in the vertical direction. The origin is the upper left corner. To calibrate this map we will use the following three calibration points (#1 to #3).

| 33 | 34 | Pixel | | WGS84 Coordinate | |
|--------------------|----|-------|------|------------------|----------|
| Reference Point | # | X | Y | Longitude | Latitude |
| Upper Left Corner | 1 | 0 | 0 | -180.0 | 90.0 |
| Lower Right Corner | 2 | 1764 | 1045 | 180.0 | -90.0 |
| Upper Right Corner | 3 | 1764 | 0 | 180.0 | 90.0 |

To determine the exact pixel position you can use Microsoft Paint (mspaint.exe) or any other pixel-editing program.

The calibration file is a plain ASCII text file. The file may contain comments. The file consists of two sections, which start with keywords encapsulated in braces.

The REFERENCE section, which is mandatory, contains the three points used to calibrate a map. Each reference point is on a single line and has the following syntax:

```
"# = <x>, <y>, <lon>, <lat>"
```

where # is the index of the reference point <x> is the horizontal and <y> is the vertical image coordinate and <lat> is the latitude and <lon> is the longitude in degrees and WGS84.

The optional MARKER section defines additional points on the map. Each point is on a single line with the syntax:

```
"# = i, <x>, <y>[, <text>]" or "# = c, <lat>, <lon>[, <text>]"
```

where # is the index of the marker point <x> is the horizontal and <y> is the vertical image coordinate or <lat> is the latitude and <lon> is the longitude in degrees and WGS84. <text> is a optional string in quotes labeling the marker point. The points must have a unique index from 1 to <num>. The maximum marker point index <num> is written to the same section on a separate line with the syntax "Count = <num>".

```

; I N F O
; -----
; File:   world.mcf
; Source: (sample data set)

; R E F E R E N C E
; -----
; 3 Points must be defined to calibrate a Map
; Parameters:
;   #       = index of the point (1 to 3)
;   x,y     = image coordinates
;   lat,lon = world coordinates
; Syntax:
;   # = <x>, <y>, <lon>, <lat>

[REFERENCE]
1 =   0,      0,   -180.0,  90.0
2 = 1764, 1045,   180.0, -90.0
3 = 1764,    0,   180.0,  90.0

; M A R K E R
; -----
; You can add points (image or world coord) to the map
; Parameters:
;   num     = number of markers that follow
;   #       = index of the point (1 to num)
;   type    = c for world or i image coordinates
;   x,y     = image coordinates
;   lat,lon = world coordinates
;   text    = quoted text decription to the marker (optional)
; Syntax:
;   Count = <num>
;   #     = <type>, <x|lon>, <y|lat>[, <text>]

[MARKER]
Count = 1
1 = c, 8.56525, 47.28519444, "u-blox ag"

```

Map calibration file: world.mcf

34.1.1.3 Map calibration tool

u-center includes a built-in calibration tool for providing coordinates to maps and photographs in supported data formats to create u-center maps. To use the tool open the map view window as seen in Figure 34 and then as seen in Figure 35 open the file of the map to be calibrated (in our example GoogleScreenShot.bmp).




Figure 34: Opening map view window





Figure 35: Opening the file of the map to be calibrated

If the file to be opened has not been calibrated, the following message will appear:



Select three points on the map and enter the calibration coordinates in the specified format as seen in Figure 36, Figure 37 and Figure 38.




Figure 36: Calibrating a map using calibration tool (position 1)




Figure 37: Calibrating a map using calibration tool (position 2)




Figure 38: Calibrating a map using calibration tool (position 3)

Following these steps the map is now calibrated and can be used with u-center for visualizing road tests etc.

34.1.9 Chart view

Chart view allows the user to conveniently view GNSS data records in graphical form. The data can be scaled in many different ways and formats. It's even possible to print the entire chart.

The examples below illustrate two different typical applications




Figure 39: Altitude as a function of Index (X = Index, Y = Alt)




Figure 40: Latitude as a function of longitude (X =Longitude, Y = Latitude)

| Function | Description | Toolbar icon |
|----------|-------------|--------------|
|----------|-------------|--------------|















| | | |
|-------------------------|---|---|
| Cursor | The position of the cursor is shown on the lower left edge of the u-center screen (Longitude, Latitude and Pixel-Position). By holding the left mouse button and moving the cursor over the chart you can measure distance from one position to another |  |
| Move | The chart inside the chart view window can be moved |  |
| Zoom In | Drawing a rectangle enlarges the chart to the new view. To zoom in the chart double-click on the chart. |  |
| Zoom Out | Drawing a rectangle decreases the chart to the new view. To zoom out the chart double-click on the chart. |  |
| Drawing Mode | The size and form of the displayed values can be changed in the menu points; the connection line between the values can be selected in the menu connect. For viewing the statically values (average, minimum, maximum, standard deviation) directly in the chart select the statistics menu |  |
| Fit Y range | Fits the Y range |  |
| Follow Y | Follow the most current Y value (the most current Y-value is always in the middle of the chart) |  |
| Index or Y value | Switch between the index and the Y value |  |
| Y value | Select the Y value to be displayed |  |
| Fit X range | Fit the X range |  |
| Follow X | Follow the most current X value (the most current X value is always in the middle of the chart) |  |
| Index or X value | Switch between the index and the X value |  |
| X value | Select the X value to be displayed |  |
| Moving average | Adds a moving average. The average is calculated over the number of most recent values, specified with the parameter. |  |

Table 16: Description of the buttons and displays in Chart View



The number of displayed epochs is set to 1800 by default (see also section 5.4).

34.1.10 Histogram view

Histogram views allow the user to view GNSS data and probability distributions (Figure 41) and print the entire histogram if desired. The number of bins (storage containers) can be set by the user.




Figure 41: Altitude Histogram View




Figure 42: Probability chart



The number of displayed epochs is set to 1800 by default (see also section 5.4).

| Function | Description | Toolbar icon |
|------------------------|--|--------------|
| Cursor | The position of the cursor is shown on the lower left edge of the u-center screen (Longitude, Latitude and Pixel-Position). By holding the left mouse button and moving the cursor over the histogram you can measure distance from one position to another. | |
| Move | The histogram inside the histogram view window can be moved. | |
| Zoom In | Drawing a rectangle enlarges the histogram to the new view. To zoom in the histogram double-click on the histogram. | |
| Zoom Out | Drawing a rectangle decreases the histogram to the new view. To zoom out the histogram double-click on the histogram. | |
| Drawing Mode | The size and form of the displayed values can be changed in the menu points; the connection line between the values can be selected in the menu connect. For viewing the statically values (average, minimum, maximum, standard deviation) directly in the histogram select the statistics menu. | |
| Probability | Displays the probability histogram (see Figure 39). | |
| Fit Probability | Fit the Probability range. | |
| Y value | Select the Y value to be displayed | |
| Bins | The number of bins | |

Table 17: Description of the buttons and displays in histogram view

34.1.11 Camera view

The camera view function enables photographs, taken during recording of log files, to be linked to the GNSS data stored in the corresponding log files. This allows a video depiction of the test, with a picture assigned to a specific point of GNSS data.




Figure 43: Camera view



Using Camera View can result in very large log files and can slow down u-center when playing such files.

34.1.12 Deviation map

The deviation map displays positions in longitude and latitude relative to a defined reference position.




Figure 44: Deviation Map

| Function | Description | Toolbar icon |
|----------|-------------|--------------|
|----------|-------------|--------------|

| | | |
|------------------------------------|--|---------------|
| Properties | 35 The reference position can be defined as: | |
| | <ul style="list-style-type: none"> - The average of all previously measured positions - The current position - A fixed, predefined value - The radius of the outer circle can be adjusted with the Max. Deviation parameter. | |
| Fit | Automatically adjusts the reference position and the maximum deviation to fit all positions into the deviation map. | |
| Track | Show track of values from the internal database. | |
| Statistics | Show statistics of the values from the internal database. | |
| Maximum deviation shortcut | Shortcut for changing the scale of the deviation map to prefixed values. The icons represent Roman numerals, with "I" corresponding to a 1 m radius of the deviation map, and "V" = 5 m, "X" = 10 m, "L" = 50 m, "C" = 100 m, "D" = 500 m, and "M" = 1000 m.. | I V X L C D M |
| Reference position shortcut | Shortcut for setting the reference position: <ul style="list-style-type: none"> - A = average position - C = current position | A C |

Table 18: Description of the buttons and displays in Deviation Map




The number of displayed epochs is set to 1800 by default (see section 5.4).



You can use the mouse scroll wheel to zoom in/out on the deviation map. Holding down the Shift key allows you to zoom in beyond the default 1 m maximum zoom.

35.1.1 Sky view

Sky view is an excellent tool for analyzing the performance of antennas as well as the conditions of the satellite observation environment. The polar plot graphically displays the averaged relative satellite signal strength (see Figure 45), the position of satellites in the sky, identifies satellites by number and indicates which satellites are being used in the receiver calculation (see section 3.1). Right-clicking the mouse on sky view allows the copying of C/N0 values in tabular form to another program.



| Function | Description | Toolbar icon |
|----------|-------------|--------------|
|----------|-------------|--------------|








| | | | |
|--------------------------|----|--|---|
| Linear projection | 36 | Displays the sky view with a linear projection. |  |
| Sine projection | | Displays the sky view with a sine projection. |  |
| C/N0 | | Displays or hides the averaged C/N0 values. |  |
| Orbits | | Displays or hides the satellite orbits. |  |
| Satellites | | Displays or hides the current satellite positions. |  |
| Coordinates | | Displays or hides the caption for the azimuth. |  |
| Elevation | | Displays or hides the caption for the elevation. |  |

Table 19: Description of the toolbar in sky view

37 Tools

This section will give an overview of the embedded tools of u-center. They can be used for different purpose and should facilitate the usage of u-blox GNSS receivers.

The tools can be found under the "Tools" menu but some of the options are only displayed when a receiver is connected to u-center. The firmware update tools also depend on the connected receiver generation.




Figure 46: Tools menu entries

37.1.1 Firmware Update u-blox 5 - 8...

This tool will allow you to update the firmware of a receiver. This only works if your receiver has a flash memory attached as the firmware has to be stored in this location.

Perform the following steps to update the firmware:

1. Establish the serial communication between u-center and the device (see also section 2.4).
2. Open firmware update tool by clicking on Tools → Firmware Update u-blox 5/6/7/M8...




Figure 47: u-blox 5 Firmware update window

3. Select the firmware image suitable for the connected receiver.

4. Select the flash definition file (only needed before u-blox receiver generation 7). This file should be provided bundled with u-center. Point to the latest file version.
5. Select the flash information structure file (only needed after and including u-blox receiver generation 7). This file should be provided bundled with u-center. Point to the latest file version.
6. Select the correct options for your receiver:

| Option | Description | Recommended |
|-------------------------------|---|-------------|
| Use this Baud rate for update | Selects the speed of the communication for updating the firmware on the receiver. Only has an effect when the receiver is connected over a serial port. | 115200 |
| Clear BBR before update | Deletes the complete battery backed memory (BBR) so that the receiver will start with the default configuration. | enabled |
| Program FIS only | Writes only the flash information structure (FIS) into the external memory and does not update the firmware. This option is used for receivers running from ROM but with an attached SQI memory (for example for logging). Only supported after and including u-blox receiver generation 7. | disabled |
| USB alternative update method | Erases the first sector of the flash memory and restarts the receiver. The receiver will then start from ROM and the flash firmware can be updated. Use this method if you want to update the firmware of a receiver connected over USB. | disabled |
| Enter Safeboot before update | Sends the command to enter safeboot. In this state, the receiver boots from the internal ring oscillator and does not rely on any external components. GNSS functionality is not started and the receiver does not output any data. Don't use this method when having the receiver connected over USB. | enabled |
| Send Training sequence | Sends the training sequence after safeboot was entered. This synchronizes the internal ring oscillator so that a communication can be established. | enabled |

7. Click on "OK".

37.1.2 Dump receiver diagnostics

This tool is used to dump the receiver diagnostic to a file. Use this tool if requested by the support team.




Figure 48: Dump receiver diagnostics tool

37.1.3 GNSS configuration

u-center is capable of getting the actual configuration of a u-blox GNSS positioning chip or module and storing it to an ASCII text file containing hexadecimal records. Such a file can be edited and stored to a u-blox GNSS device again. By clicking the menu "Tools -> GNSS Configuration..." of u-center, the GNSS Configuration dialog opens. The following functions are available:




Figure 49: GNSS configuration tool

- Specify the name of a new configuration file to store current configuration from the u-blox GNSS device
- Specify the name of an existing configuration file and load this configuration into the u-blox GNSS device
- A flag can be set to force storing the configuration into the Battery Backed RAM (BBR) or Flash.

37.1.3.1 Read/Write configuration files

1. Connect to the device.
2. Open Tools / GNSS Configuration.
3. To read an existing configuration file, select the name of the file, then click on "File > GNSS" button. The GNSS Configuration window then closes and the progress window pops up, showing the configuration being sent to the receiver. This progress window closes after finishing the transfer without error.



Select "store configuration into BBR/Flash" checkbox if the parameters need to be stored into the device's non-volatile memory (BBR/Flash).



Sending a configuration to a u-blox GNSS device may fail due to a baud rate change on the current serial port of the receiver to which the configuration is being sent. If this happens, simply change the u-center baud rate and send the configuration again.

To write a new configuration file, click on "GNSS > File". The GNSS Configuration window closes and the progress window pops up, showing the configurations being polled and stored into a local file in ASCII format.

If reading or writing configuration data fails too frequently, try to increase the number of retries u-center should do on a single message if one fails.

The user can abort the transfer by clicking the "Abort" button. It's not possible to close the window unless transfer has completed or the user aborted it.



It is not recommended to read/write configuration while the u-blox GNSS device is in sleep mode.

37.1.3.2 Editing configuration file




Figure 50: Content Configuration File

When clicking the “Edit” button in the GNSS Configuration dialog, the Notepad editor opens (standard Windows software). Configurations are stored the following way:

- The first line contains the version of the u-blox GNSS receiver where the configuration is from. **Never change this line!**
- For the second and following lines, each line contains the same: <class ID>-<message ID> - <hexadecimal byte code of the message>. The byte code consists of class and message IDs (2 bytes), payload length (2 bytes), payload (payload length bytes). The sync characters and the checksum are not included. They will be calculated automatically.

Refer to u-blox Receiver Description including Protocol Specification for detailed information and ranges.

37.1.4 Hotkeys

The Tools Menu allows administrating the Hotkeys defined in the Message View. Refer to section 28.1.2 for more information on the Hotkeys.

37.1.5 Preferences

The preferences tool can be used to configure a number of u-center parameters.

38 How To

38.1 Change baud rate of receiver

1. Connect to the device.
2. Open View / Messages View (Hotkey: F9).
3. Select UBX-CFG-PRT.
4. Poll the current configuration from the receiver (Poll).
5. Change the setting to the desired baud rate.
6. Send the message to the receiver (Send).




Figure 51: Changing baud rate (using UBX-CFG-PRT)

38.2 Save parameters to receiver non-volatile memory (BBR/Flash)

There are 2 ways to save parameters to the receiver's non-volatile memory (BBR/Flash).

38.2.1 Saving parameters with UBX-CFG-CFG

1. Connect to the device.
2. Open View / Messages View (Hotkey: F9).
3. Select UBX-CFG-CFG.
4. Select "save current configuration" (see Figure 52).
5. Send the message to the receiver (Send).




Figure 52: Saving Parameters (using UBX-CFG-CFG)

38.2.2 Saving parameters with GNSS configuration

Refer to 37.1.3.1 step 3

38.3 Recording/playing a log file

u-center allows recording and playing log files. Use the player controls, to record or playback a log file. Select the log file to be opened through the file menu tool bar. The series of buttons in the player toolbar can be used to

navigate through the log file. The records will be displayed on the navigation display window, in the same way that live GNSS data is displayed when using u-center.


38.4 Conduct sensitivity tests

u-center is a useful tool for conducting sensitivity tests of GNSS positioning chips and modules and receiver designs. To do so, under open sky conditions record a log file of the receiver to be tested and an Evaluation Kit as reference. Make sure that the log files are recorded under the same conditions. Using the Statistic View or Table View windows from u-center, compare the C/N0 values of the five strongest satellites. With Table view, export the values to a spreadsheet for analysis.

38.5 Read/write configuration files

Refer to 37.1.3.1.

38.6 Set GNSS system configuration

1. Connect to the device.
2. Open View / Messages View (Hotkey: F9).
3. Select UBX-CFG-GNSS.
4. Place or remove the checkmark for the desired GNSS under "enable".
5. Send the message to the receiver ( Send).

The following Figure 53 shows an example that configures the device to receive only GLONASS.





Figure 53: GNSS configuration (using UBX-CFG-GNSS)

38.7 Activating PPP (EVK-6PPP only)

1. Connect to the device.
2. Open View / Message View.
3. Select UBX-CFG-NAVX5 window.
4. Place or remove the checkmark for "Use PPP".
5. Send the message to the receiver ( Send).




Figure 54: How to activate and deactivate PPP using UBX-CFG-NAVX5

38.8 Change Epoch Detection Method

u-center looks for epochs in the incoming messages from the receiver, and uses them as a “heartbeat” to trigger view updates and calculate the statistics. To detect new epochs, u-center examines various groups of fields in the incoming message stream. It is possible to specify which field groups u-center is interested in for epoch detection, and opening the dialog under “Receiver” → “Epoch detection...” allows the user to do this.




Figure 55: Select epoch detection method

Where the following options can be configured:

| Option | Description | Default |
|-------------|---|---------|
| iTOW | Monitor the “iTOW” database element. Trigger an epoch if a difference is seen. Typically UBX-NAV messages cause this trigger. | Yes |
| HNR TOW | Monitor the “NAV-HNR iTOW” database element. Trigger an epoch if a difference is seen. HNR based messages cause this trigger. | No |
| UTC-TIME | Monitor the “UTC” database element. Trigger an epoch if a difference is seen. Typically NMEA messages cause this trigger. | Yes |
| GPS-TIME | Monitor the “GPS time” database element. Trigger an epoch if a difference is seen. Typically PUBX messages cause this trigger. | Yes |
| NAV-EOE | Monitor for incoming UBX-NAV-EOE messages. Trigger an epoch if one is seen. | Yes |
| ITFM Status | Monitor the “ITFM Status” database element. Trigger an epoch if a difference is seen. The UBX-RXM-INTF message causes this trigger. | Yes |
| NMEA repeat | Monitor for NMEA messages. Trigger an epoch if the same NMEA message is seen twice since the last epoch. Excluding GxGRS and GxGSA. | Yes |

Table 20: Epoch detection method options

The default configuration can be restored by clicking the “Restore historical defaults” button.

39 Troubleshooting

NMEA or UBX protocol is not available in the Messages View

u-center uses dynamic link libraries (DLL). The installation program will automatically install the required DLLs into the u-center program directory. Should you try to copy a u-center installation from one location to another, make sure you also copy the DLL files. Verify, the version of u-center matches the DLL version.

u-center doesn't display all messages

Make sure the baud rate is sufficient. If the bandwidth is insufficient, receivers based on the ANTARIS™ Technology will skip excessive messages.

Some serial port cards/adapters (i.e. USB to RS232 converter) frequently generate errors. If a communication error occurs during while u-center receives a message, the message will be discarded.

u-center loses the connection to the device

u-blox GNSS positioning chips and modules have an autobauding feature. If frequent communication errors occur (i.e. due to problems with the serial port), the connection may be lost as u-center and the device will autonomously try to adjust the baud rate. Do not enable the u-center autobauding feature if the device has the autobauding enabled.

Some COM port are not shown in the port list

Only the COM ports that are available on your computer will show up in the COM port drop down list. If a COM port is grayed out, another application in the computer is using it.

PC is very slow when u-center runs

If a high value of epochs is selected, the display in real-time cannot be guaranteed, especially when many graphical views are open. u-center does not update minimized views and console in real-time. Close or minimize as many of the graphical views and consoles as possible and u-center will run faster.

Log file / Data are only partly displayed

The number of epochs displayed in u-center is limited in order to allow an efficient analysis of larger logfiles. The limitation is set to 1800 epochs by default. That means if an epoch is available every second you can analyze data for as much as 30 minutes. After this time the oldest values are discarded. Data stored to a log file are not affected by the database limitation. Refer to section 5.4 for instructions on how to increase this limit.

When planning long-term observations, it's recommended to start recording a log file before analysis begins.

Output messages are not updated in the Messages View

Make sure that the protocol you would like to receive is enabled. If so, double-click on the desired output message. Double-clicking on an output message enables or disables the periodic message update if the respective protocol is active. Alternatively, select the desired input or output message and press the "Poll" button.

If you would like to get UBX-INF () messages in the log file, configure the receiver accordingly with the UBX-CFG-INF input message.

No logfile is recorded

After a new logfile is created, logging will not automatically start but only after selecting the Record button in the Player Toolbar.

Related documents

- [1] GPS Compendium, Doc No GPS-X-02007
- [2] u-blox 5 Receiver Description including Protocol Specification, Docu. No GPS.G5-X-07036
- [3] u-blox 6 Receiver Description including Protocol Specification, Docu. No GPS.G6-SW-10018
- [4] u-blox 7 Receiver Description including Protocol Specification V14, Docu. No GPS.G7-SW-12001
- [5] u-blox 8 / u-blox M8 Receiver Description Including Protocol Specification (Public version), Docu. No. UBX-13003221



For regular updates to u-blox documentation and to receive product change notifications, register on our homepage.

Revision history

| Revision | Date | Name | Status / Comments |
|----------|-------------|------|---|
| - | 08-Oct-2008 | tgri | Initial release |
| A | 22-Jul-2009 | tgri | New CI |
| A1 | 17-Feb-2011 | tgri | Third party libraries |
| B | 1-Nov-2011 | tgri | Google Earth View added |
| C | 03-Jun-2012 | khir | Updated for u-center 6.3. GNSS configuration added Last revision with document number GPS-SW-08007 |
| R06 | 09-Dec-2013 | maba | Update for u-center 8.01 and u-blox 7 and M8 generations |
| R07 | 01-Oct-2014 | jbow | Packet view update describing message direction indicators |
| R08 | 23-Feb-2015 | zyha | Updated menu pictures and shortcut key list corresponding to latest version. |
| R09 | 04-Sep-2015 | smos | Updated Contact page |
| R10 | 12-Dec-2015 | maba | Remove Google Earth support |
| R11 | 29-Mar-2016 | maba | Epoch detection, DGNSS interface and receiver status icons description added, legacy aiding marked deprecated, pictures updated |

Contact

For complete contact information visit us at www.u-blox.com

Offices

North, Central and South America

u-blox America, Inc.

Phone: +1 703 483 3180
E-mail: info_us@u-blox.com

Regional Office West Coast:

Phone: +1 408 573 3640
E-mail: info_us@u-blox.com

Technical Support:

Phone: +1 703 483 3185
E-mail: support_us@u-blox.com

Headquarters Europe, Middle East, Africa

u-blox AG

Phone: +41 44 722 74 44
E-mail: info@u-blox.com
Support: support@u-blox.com

Asia, Australia, Pacific

u-blox Singapore Pte. Ltd.

Phone: +65 6734 3811
E-mail: info_ap@u-blox.com
Support: support_ap@u-blox.com

Regional Office Australia:

Phone: +61 2 8448 2016
E-mail: info_anz@u-blox.com
Support: support_ap@u-blox.com

Regional Office China (Beijing):

Phone: +86 10 68 133 545
E-mail: info_cn@u-blox.com
Support: support_cn@u-blox.com

Regional Office China (Chongqing):

Phone: +86 23 6815 1588
E-mail: info_cn@u-blox.com
Support: support_cn@u-blox.com

Regional Office China (Shanghai):

Phone: +86 21 6090 4832
E-mail: info_cn@u-blox.com
Support: support_cn@u-blox.com

Regional Office China (Shenzhen):

Phone: +86 755 8627 1083
E-mail: info_cn@u-blox.com
Support: support_cn@u-blox.com

Regional Office India:

Phone: +91 80 4050 9200
E-mail: info_in@u-blox.com
Support: support_in@u-blox.com

Regional Office Japan (Osaka):

Phone: +81 6 6941 3660
E-mail: info_jp@u-blox.com
Support: support_jp@u-blox.com

Regional Office Japan (Tokyo):

Phone: +81 3 5775 3850
E-mail: info_jp@u-blox.com
Support: support_jp@u-blox.com

Regional Office Korea:

Phone: +82 2 542 0861
E-mail: info_kr@u-blox.com
Support: support_kr@u-blox.com

Regional Office Taiwan:

Phone: +886 2 2657 1090
E-mail: info_tw@u-blox.com
Support: support_tw@u-blox.com