

ANTENNA

Wiring an external high-power DPDT 5V relay for a high power transceiver

TRANSMIT PATH

LONG RF CABLE → to J3 of the Phantom PSU PCB

NC = Normally Closed Contact
NO = Normally Open Contact
Relay Coil (5V DC) parallel to LNA PCB's K1 coil

